


Installation Instructions

2005-2006 Pontiac GTO dual aft-cat system

605GTO5



**Please check Parts List below
to insure that all parts
are included in the product box !**



**Note: anti-seize
should be applied
to all fastener
threads, pipe slip
joints and mating
surfaces of
ball /socket
connections.**

Parts List and Description

(A)	PN	6GTO5XM	- center mount X-muffler
(B)	PN	6GTO5LP	- left intermediate pipe
(C)	PN	6GTO5RP	- right intermediate pipe
(D)	PN	6GTO5LT	- left tailpipe w/resonator
(E)	PN	6GTO5RT	- right tailpipe w/resonator

Hardware List

4 -	2.5" band clamps
4 -	3/8" x 1.5" bolts
4 -	3/8" flat washers
4 -	3/8" flanged nuts
1 -	anti-seize compound

Installation instructions:

1. Raise and support vehicle.
2. Lubricate all stock rubber exhaust hangers and fasteners attaching center resonator to converter pipes and also nuts on muffler attachment flanges.
3. Remove fasteners from muffler attachment flanges; push mufflers towards rear of vehicle to clear flange studs and then pull down and forward to remove muffler from rear rubber hangers.
4. Remove rubber hangers from rods on intermediate pipes in the center of vehicle.
5. Remove fasteners from flanges at resonator/converter pipe connection and remove resonator/mid pipe assembly from vehicle.
6. Remove the intermediate pipe rubber hanger from the stock location on driver side pipe and re-install on the adjacent exposed rod, which points to the outside of the car. Be sure to replace retainer clip.
7. Install supplied X-muffler onto converter pipes with supplied 3/8" hardware.
8. Place two supplied clamps over mid-pipe inlets and install pipes over X-muffler outlets. Insert hanger rods into corresponding rubber hangers.
9. Rotate mid-pipes to position hanger rods parallel to the ground and tighten clamps and fasteners on X-muffler fully.
10. Place two supplied clamps over tailpipes with polished resonators and install onto mid-pipe outlets.
11. Insert hanger rods on tailpipes into rear-most rubber hangers; inside rods will position rubber hangers in a horizontal position when installed correctly.
12. Align system and tighten all clamps.

**FOR TECHNICAL ASSISTANCE CALL TOLL-FREE (866) 782-3283
2900 East La Jolla Anaheim, CA 92806**