

PROFLEX Commander for E60 M5 installation instructions

1. We recommend removing the air boxes, removing the plenum, and loosening the coolant expansion tank to get to fuel fitting located on driver's side firewall.
2. The included 90 degree fitting plugs into car's hard line, the straight fitting plugs on to the included fuel sensor and the included custom fuel fitting goes on the other side of the fuel sensor with the stock line plugging into the custom fitting.
3. Install all the injector connectors. We recommend zip tying the wires to the fuel rail so they don't interfere with the throttle control.
4. Plug the harness into the fuel sensor.
5. The ground wire on the harness goes under the cabin air filter on the passenger side of the car at the DME ground.
6. Mount the PROFLEX Commander under the cowling at the back of the plenum or in compartment with brake booster.
7. After installation start the car **before** plugging in the PROFLEX Commander. If the car starts and runs normally then the installation is correct. Turn off the car, plug in the PROFLEX Commander, and start the car again.
8. You can now add E85 as your E60 M5 is now fully flex fuel!