

### 3.6L RIPP Catch Can Install Instructions



1. Attach the RIPP Catch Can using the provided 14mm bolt to the tab located behind the passenger side headlight.
2. Remove the factory PCV hardline which connects to PCV to the bung behind the throttle body. This part is no longer needed.
3. Connect the supplied hose from the inlet of the catch can to the factory PCV on the back of the valve cover. Insert the 90° fitting into the factory rubber fitting on the factory PCV.
4. Connect the supplied hose from the outlet of the catch to the bung behind the throttle body.
5. **CRITICAL STEP: Only applicable if your vehicle is supercharged.** Install the RIPP PCV into outlet hose and onto the intake manifold bung. The arrows on the PCV must face toward the intake manifold. This PCV shuts when the manifold is pressurized by the supercharger. Failure to install the RIPP PCV this will allow boost pressure to enter the catch can and crank case.

Note: Catch Cans are not included with supercharger kits and must be purchased separately.

